

Walter™ 3


Contents Update Guideline

A Child's First Library of Learning Book 17



Step 1 Download the audio file

- Download the zip file, 'A Child's First Library of Learning_Book 17 Audio Files', from the link below:
<https://www.etllearning.com/download-india/>



Walter 3 Contents Update

Guidelines:

A Child's First Library of Learning Book 17

Early Learning Program Flashcards



Download Audio Files:

A Child's First Library of Learning Book 17 Audio Files

Early Learning Program Flashcards Audio Files

Step 2 Extract the zip file

- Right click the file, choose **7-zip**, choose **Extract files**, then click **OK**.



Step 3 Connect your Walter™ 3 to your computer

- Connect your Walter™ 3 to your computer by using the Micro-USB cable provided.




Step 4 Open the folder named 'oid'

- Look for the connected Walter™ 3 (on either D: or E: drive), then open the folder named '**oid**'.




Step 5 Delete the previous file

- Delete the files named 'CN-CFL17.bin' & 'English-CFL17.bin'.



Step 6 Copy the updated audio files to Walter™ 3

- Copy the extracted files, 'CN-CFL17.bin' & 'English-CFL 17.bin', to 'oid' folder to complete the update.





The End